



NO.	PARTS NAME	NO.	PARTS NAME	NO.	PARTS NAME	NO.	PARTS NAME	NO.	PARTS NAME	NO.	PARTS NAME		
1.	Cover screw	13.	Spool shaft	25.	"E" Washer	37.	Pre-program key pin	49.	Drive shaft coat washer	61.	Handle nail	96.	Handle nail pallet
2.	Cover	14.	Spool cannulation	26.	Alert ratchet	38.	"O" ring	50.	Drive shaft	63.	Handle knob screws	97.	Handle knob screws
3.	"E" washer	15.	Spool	27.	Alert ratchet screws	39.	Drag tension knob	51.	Ball bearing	66.	Feet seat screw sleeve	98.	Handle knob
4.	Drag plate undersleeve	16.	Small ring	28.	Bearing cover	40.	Ball bearing	52.	One-way	67.	Reel foot		
5.	Spool spring washer	17.	Rear drag plate	29.	Sound nail	41.	Spool shaft screw	53.	Drive shaft coat	68.	Reel foot screws		
6.	Rear drag plate	18.	Spool spring washer	30.	Sound washer	42.	Drag knob cover	54.	Right plate	69.	Rod clamp		
7.	Snap ring	19.	Spool spring washer	31.	Nail cover	43.	Frame	55.	Side plate screws	70.	Fixed screws		
8.	Spool spring washer	20.	Spool spring washer	32.	Sound spring	44.	Bearing ring	56.	Washer	71.	Handle bolt washer		
9.	Spring	21.	High speed pinion	33.	Screw for bearing cover	45.	Gear block	57.	Washer	72.	Anti-reverse ratchet		
10.	Spool ring	22.	Seal/leak/lever	34.	Drag control lever/washer	46.	Close cover screws	58.	Handle arm	73.	Spring cover for silence		
11.	Drag plate	23.	Washer	35.	Drag control lever	47.	Close cover screws	59.	Shaft screw	74.	Friction spring		
12.	Ball bearing	24.	Alarm sound gear	36.	Pre-program plate	48.	Drive gear-high speed	60.	Side plate screws	95.	Handle bush		