



Key No.	Part No.	Part Name	Key No.	Part No.	Part Name
1	5K275832	Palm Side Cover	41	6K177001	Washer
2	5K134801	Lock Pin	42	6K259153	Tension Nut
3	6K974401	Coil Spring	43	6K311307	Screw
4	5K102301	Magnet Holder Assembly	44	5K170601	Ball Bearing
5	5K047001	Tap Screw	45	63201402	Retainer
6	6K164605	Washer	46	5K134901	Bearing Plate
7	5K474501	Ball Bearing	47	63535902	Screw
8	6K468301	Ring	48	5K093618	Gear Metal
9	5K350306	Spool Assembly (1 Ball Bearing)	49	6K258101	Gear
10	6K311315	Screw	50	6K893602	Ratchet
11	6K311307	Screw	51	5K027101	Washer
12	6K395604	Screw	52	5K243905	Drive Gear
13	6B339801	Retainer	53	5K039901	Washer-L
14	6K456801	Bush	54	5K040001	Washer-D
15	6K931104	Level Wind Assembly	55	5K242801	One way clutch Assembly
16	6K256501	Level Wind Pin	56	6K859203	Sleeve
17	6K148801	Washer	57	5K582205	Ball Bearing
18	6K704403	Level Wind Nut	58	6K177302	Washer
19	6K456403	Pipe	59	6K259201	Leaf Spring Assembly
20	5K095605	Worm Shaft	60	5K027201	Spring Washer
21	6E096503	Washer	61	6K193601	Washer
22	6K469301	Worm Pinion	62	5K0840B8	Star Drag Assembly
23	6B339801	Retainer	63	6K161404	Leaf Spring
24	5K130831	Hood	64	5K241234	Handle Assembly
25	6K930403	Pillar	65	5K181831	Handle Nut
26	5K132834	Frame Assembly	66	5K005015	Retainer
27	6K977206	Thumb Bar Assembly	67	63520407	Screw
28	5K119001	Kick Lever Spring	68	5K132423	Control Dial
29	5K130601	Kick Lever	69	6K974701	Leaf Spring
30	5K093401	Clutch Cam Spring	70	6K180201	O-Ring
31	5K130701	Clutch Cam	71	5K137901	Slide Cam-B
32	6K787601	Screw	72	5K100501	Coil Spring
33	6K787601	Screw	73	5K284701	Slide Cam-A
34	5K093701	Clutch	74	5K275901	Spool Cover
35	6K942501	Coil Spring	75	6K509702	Screw
36	5K310501	Pinion	77	6K176905	Collar
37	5K275740	Gear Side Cover Assembly	78	6K261702	Bush
38	6K176501	O-Ring	79	6K164403	Washer
39	6K176801	Bearing			
40	6K164605	Washer			