



Key No.	Part No.	Part Name	Key No.	Part No.	Part Name
1	5K276129	Palm Side Cover	41	6K177001	Washer
2	5K134801	Lock Pin	42	6K259153	Tension Nut
3	6K974401	Coil Spring	43	6K311307	Screw
4	5K102301	Magnet Holder Assembly	44	5K170601	Ball Bearing
5	5K047001	Tap Screw	45	63201402	Retainer
6	6K164605	Washer	46	5K134901	Bearing Plate
7	6K474501	Ball Bearing	47	63535902	Screw
8	6K468301	Ring	48	5K093619	Gear Metal
9	5K350306	Spool Assembly (1 Ball Bearing)	49	6K258101	Gear
10	6K311315	Screw	50	6K893602	Ratchet
11	6K311307	Screw	51	5K027101	Washer
12	6K395604	Screw	52	5K243906	Drive Gear
13	6B339801	Retainer	53	5K039901	Washer-L
14	6K456801	Bush	54	5K040001	Washer-D
15	6K931104	Level Wind Assembly	55	5K242801	One way clutch Assembly
16	6K256501	Level Wind Pin	56	6K859203	Sleeve
17	6K148801	Washer	57	6K582205	Ball Bearing
18	6K704403	Level Wind Nut	58	6K177302	Washer
19	6K456403	Pipe	59	6K259201	Leaf Spring Assembly
20	5K095605	Worm Shaft	60	5K027201	Spring Washer
21	6E096503	Washer	61	6K193601	Washer
22	6K469301	Worm Pinion	62	5K0840B9	Star Drag Assembly
23	6B339801	Retainer	63	6K161404	Leaf Spring
24	5K136727	Hood	64	5K241235	Handle Assembly
25	6K930403	Pillar	65	5K181832	Handle Nut
26	5K138932	Frame Assembly	66	5K005015	Retainer
27	5K138303	Thumb Bar Assembly	67	63508914	Screw
28	5K138201	Kick Lever Spring	68	5K132423	Control Dial
29	5K137301	Kick Lever	69	6K974701	Leaf Spring
30	5K138401	Clutch Cam Spring	70	6K180201	O-Ring
31	5K137201	Clutch Cam	71	5K137901	Slide Cam-B
32	6K787601	Screw	72	5K100501	Coil Spring
33	6K787601	Screw	73	5K284701	Slide Cam-A
34	5K133401	Clutch	74	5K276201	Spool Cover
35	6K942501	Coil Spring	75	6K509702	Screw
36	5K310502	Pinion	76	6E096501	Washer
37	5K276029	Gear Side Cover Assembly	77	6K176905	Collar
38	6K176501	O-Ring	78	6K261702	Bush
39	6K176801	Bearing	79	6K164403	Washer
40	6K164605	Washer			