



**BALLISTIC MQ LT 1000D/2500D/2500D-XH/3000D/4000D-C**

\*Please order by parts number, not key number.

Key No.	Parts Name	Parts No.				
		1000D	2500D	2500D-XH	3000D	4000D-C
1	Drag Knob	60644401	60610401	60610401	60610401	60704601
2	Drag Washer Retainer	60346101	60346101	60346101	60346101	60346101
3	Key Washer	60621901	60621901	60621901	60621901	60621901
4	Drag Washer	6J678901	6J678901	6J678901	6J678901	6J678901
5	Eared Washer	6J546902	6J546902	6J546902	6J546902	6J546902
6	Drag disc Washer	6J549001	6J549001	6J549001	6J549001	6J549001
7	Bearing Retainer (A)	6B358701	6B358701	6B358701	6B358701	6B358701
8	Ball Bearing (A)	66212503	66212503	66212503	66212503	66212503
2-12	Spool Assembly	60745401	60745401	60745401	60745401	60745401
10	Line Stopper Plate	60376701	60345601	60345601	60345601	60353501
11	Line Stopper	60345501	60345501	60345501	60345501	60345501
12	Line Stopper Spring	60345701	60345701	60345701	60345701	60345701
13	Washer (A)	6J546300	6J546300	6J546300	6J546300	6J546300
14	Screw (A)	6J558201	6J558201	6J558201	6J558201	6J558201
15	Spool Metal	6J564101	6J549501	6J549501	6J549501	6J549501
16	Ball Bearing (B)	6E306801	6E306801	6E306801	6E306801	6E306801
17	Washer (B)	6J602201	6J602201	6J602201	6J602201	6J602201
18	Click Leaf Spring Holder	60798201	60798201	60798201	60798201	60798201
19	Spool Click Leaf Spring	60797701	60797701	60797701	60797701	60797701
20	Packing (A)	6H986901	6H986901	6H986901	6H986901	6H986901
21	Rotor Nut	60748401	60735801	60735801	60735801	60735801
22	Collar (A)	60858100	60858100	60858100	60858100	60858100
23	Washer (C)	63727602	63727602	63727602	63727602	63727602
24	Screw (B)	6H022701	6H022701	6H022701	6H022701	6H022701
25	Rotor	60139544	60343030	60343030	60120541	60351827
26	Bail Trip Lever Spring	6H443301	6H413601	6H413601	6H413601	6H413601
27	Bail Trip Lever	60139601	60343101	60343101	60120701	60351901
28	Screw (C)	6H417701	6H417701	6H417701	6H417701	6H417701
29	Bail Spring Shaft	60139801	60343301	60343301	60121201	60129501
30	Bail Spring Plate	6H576101	6H576101	6H576101	6H576101	6H576101
31	Bail Spring	6H442401	6J642801	6J642801	6H545701	6H414201
32	Bail Spring Holder	60121501	60121501	60121501	60121501	60121501
33	Cover (A)	60146501	60343501	60343501	60121801	60352101
34	Screw (D)	60342901	60342901	60342901	60342901	60342901
35	Bail Arm	60609701	60609701	60609701	60609701	60609701
36	Collar (B)	60121701	60121701	60121701	60121701	60121701
37	Screw (E)	60343401	60343401	60343401	60343401	60343401
38	Screw (F)	6H697701	6H697701	6H697701	6H697701	6H697701
39	Collar (C)	60620901	60620901	60620901	60620901	60620901
40	Packing (B)	6H038301	6H038301	6H038301	6H038301	6H038301
41	Ball Bearing (C)	66686903	66686903	66686903	66686903	66686903
42	Collar (D)	6H960901	6H960901	6H960901	6H960901	6H960901
43	Line Roller	66686702	66686702	66686702	66686702	66686702
44	Collar (E)	6H960801	6H960801	6H960801	6H960801	6H960801
45	Collar (F)	60610001	60610001	60610001	60610001	60610001
46	Bail Assembly	60646201	60609801	60609801	60667301	60704101
47	Screw (G)	66171402	66171402	66171402	66171402	66171402

Key No.	Parts Name	Parts No.				
		1000D	2500D	2500D-XH	3000D	4000D-C
48	Magnet Assembly	6J675201	6J675201	6J675201	6J675201	6J675201
49	"O"-Ring (A)	6J354801	6J354801	6J354801	6J354801	6J354801
50	Cap	60609601	60609601	60609601	60609601	60609601
51	Washer (D)	6J639900	6J639900	6J639900	6J639900	6J639900
52	Roller Clutch	6J388402	6J388402	6J388402	6J388402	6J388402
53	Spacing Sleeve	6J536102	6J536102	6J536102	6J536102	6J536102
54	Collar (G)	60609001	60609001	60609001	60609001	60609001
55	Screw (H)	60195701	60195701	60195701	60195701	60195701
56	Bearing Retainer (B)	60621201	60621201	60621201	60621201	60621201
57	Ball Bearing (D)	66467302	66467302	66467302	66467302	66467302
58	Washer (E)	63758500	63758500	63758500	63758500	63758500
59-79	Pinion+Drive Gear Set	62700650	62700712	62700629	62700685	62700685
60	Spring Washer	6H931701	6H931701	6H931701	6H931701	6H931701
61	Ball Bearing (E)	6H959601	6G466202	6G466202	6G466202	6G466202
62	Washer (F)	6G466103	6G466103	6G466103	6G466103	6G466103
63	Collar (H)	6J387701	6J387701	6J387701	6J387701	6J387701
64	Screw (I)	60621301	60621301	60621301	60621301	60621301
65	Body	60642601	60607701	60607701	60665701	60665701
66	Packing (C)	60643901	60609401	60609401	60667101	60667101
67	Rear Cover	60644001	60609501	60609501	60667201	60667201
68	Screw (J)	60621101	60621101	60621101	60621101	60621101
69	Collar (I)	60609201	60609201	60609201	60609201	60609201
70	Stabilizer Bar	60609302	60609301	60609301	60126305	60126305
71	Main Shaft	60643201	60608201	60608201	60666201	60703801
72	Washer (G)	6H607901	6J644701	6J644701	6J644701	6J644701
73	Oscillate Gear	60643101	60608101	60608101	60666101	60703701
74	"O"-Ring (B)	66683301	6H770601	6H770601	66466001	66466001
75	Washer (H)	6H129200	6H129200	6H129200	6H129200	6H129200
76	Ball Bearing (F)	66469005	66469005	66469005	66469005	66469005
77	Screw (K)	60126101	60126101	60126101	60126101	60126101
78	"O"-Ring (C)	66670501	66670501	66670501	66670501	66670501
80	Washer (I)	63758500	63758500	63758500	63758500	63758500
81	Ball Bearing (G)	66522706	66467302	66467302	66467302	66467302
82	"O"-Ring (D)	6J588801	6J553001	6J553001	6J571501	6J571501
83	Side Cover (A)	60643804	60609104	60609105	60666904	60666904
84	Packing (D)	6J130201	6J130201	6J130201	6J130201	6J130201
85	Handle Assembly	60726801	60698101	60698101	60750601	60704701
86	Ball Bearing (H)	66522706	66522706	66522706	66522706	66522706
87	Side Cover (B)	60642901	60607901	60607901	60665901	60665901
88	"O"-Ring (E)	6H816401	60608001	60608001	60666001	60666001
89	Bearing Retainer (C)	66472401	66472401	66472401	66472401	66472401
90	"O"-Ring (F)	6H617001	6H617001	6H617001	6H617001	6H617001
91	Side Cover (C)	60608903	60608903	60608903	60608903	60608903
92	"O"-Ring (G)	66162401	66162401	66162401	66162401	66162401
93	Handle Screw	60345101	60345101	60345101	60345101	60345101
94	Washer (J)	63754102	63754102	63754102	63754102	63754102