




SILVERCREEK X LT 2000S-XH/2500S-XH

PARTS LIST

SPINNING REEL



*Please order by parts number, not key number.

*Veuillez indiquer le numéro de la pièce (Non Key No.)

SILVERCREEK X LT 2000S-XH/2500S-XH

Key No.	Parts Name	Parts No.		Key No.	Parts Name	Parts No.	
		2000S-XH	2500S-XH			2000S-XH	2500S-XH
1	Drag Knob	6Q376801	6Q346201	36	Screw (G)	6Q126201	6Q126201
2	Drag Washer Retainer	6Q346101	6Q346101	37	Bearing Retainer (A)	6Q195601	6Q195601
3	Key Washer	6Q621901	6Q621901	38	Ball Bearing (A)	6Q467302	6Q467302
4	Drag Washer	6J678901	6J678901	39	Washer (D)	63758500	63758500
2-5	Spool Assembly	6Q885201	6Q885501	40	Pinion Gear	6Q409201	6Q360301
6	Washer (A)	6E398000	6E398000	41	Spring Washer	6H931701	6H931701
7	Washer (B)	6Q348502	6Q348502	42	Ball Bearing (B)	6H959601	6H959601
8	Spool Click Leaf Spring	6Q797701	6Q797701	43	Collar (E)	6J387701	---
9	Click Leaf Spring Holder	6Q798201	6Q798201	44	Body	6Q884701	6Q884801
10	Washer (C)	6Q344001	6Q344001	45	Main Shaft	6Q375301	6Q341501
11	Rotor Nut	6Q122401	6Q122401	46	Stabilizer Bar (A)	---	6Q126301
12	Screw (A)	6H022701	6H022701	47	Stabilizer Bar (B)	6Q119104	6Q119101
13	Rotor	6Q139554	6Q343042	48	Anti-Reverse Cam	6Q118101	6Q118101
14	Bail Trip Lever Spring	6H443301	6H413601	49	Anti-Reverse Cam Spring	6H697801	6H697801
15	Bail Trip Lever	6Q139601	6Q343101	50	Anti-Reverse Lever	6Q118001	6Q118001
16	Screw (B)	6H417701	6H417701	51	Rear Cover	6Q626501	6Q626401
17	Bail Spring Shaft	6Q139801	6Q343301	52	Screw (H)	6Q342901	6Q342901
18	Bail Spring Plate	6H576101	6H576101	53	Washer (E)	6H607902	6H595701
19	Bail Spring	6H442401	6J642801	54	Oscillate Gear	6Q375201	6Q139001
20	Bail Spring Holder	6Q121501	6Q121501	55	"O"-Ring (A)	6H770601	6H770601
21	Cover (A)	6Q146501	6Q343501	56	Washer (F)	6H129200	6H129200
22	Screw (C)	6Q342901	6Q342901	57	Ball Bearing (C)	6Q469005	6Q469005
23	Bail Arm	6Q121626	6Q121626	58	Screw (I)	6Q126101	6Q126101
24	Collar (A)	6Q121701	6Q121701	59	"O"-Ring (B)	6G670501	6G670501
25	Screw (D)	6Q343401	6Q343401	60	Drive Gear	6Q409301	6Q360401
26	Screw (E)	6G195602	6G195602	61	Washer (G)	63758500	63758500
27	Collar (B)	6G195501	6G195501	62	Ball Bearing (D)	6Q467302	6Q467302
28	Collar (C)	6G220701	6G220701	63	Side Cover	6Q884901	6Q885001
29	Line Roller	6J089902	6J089902	64	Screw (J)	6Q342701	6Q342701
30	Collar (D)	6Q203401	6Q203401	65	Screw (K)	6Q342601	6Q342601
31	Bail Assembly	6Q788301	6Q777001	66	Handle Assembly	6Q885801	6Q886001
32	Screw (F)	6G837101	6G837101	67	Ball Bearing (E)	6G522706	6G522706
33	Cap	6Q139401	6Q139401	68	Bearing Retainer (B)	6G472401	6G472401
34	Roller Clutch	6Q308301	6Q308301	69	Handle Screw	6Q345101	6Q345101
35	Spacing Sleeve	6J001401	6J001401				