



### TMC-8000 PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21009361	Main body	708	27080069	Oscillating slider
105	21050145	Pinion bearing fixed bushing	716	27160010	Oscillation slider plate
105-1	21056580	Pinion bearing fixed plate	718	27180613	Main shaft
108	21081599	Cap	719	27190005	Click gear
200	22004690	Side plate	722	27220005	Click gear washer
201	22011198	Main body decoration	725	27250019	Transmission gear bushing
201-1	22011199	Side plate decoration	725-1	27250002	Transmission gear bushing
300	23005253	Rotor	800	28000256	Anti-reverse/anti-re lever
301	23012363	Bail arm	800-1	28000327	Anti-reverse/anti-re lever
304	23049866	Bail arm cover	801	28010039	Anti-re lever spring
305	23050215	Kick lever	0910529	0910529	Ball bearing
307	23071981	Bail holder	0910184	0910184	Ball bearing
309	23090037	Bail arm support pin	0910139	0910139	Ball bearing
310	23100070	Compression spring	0910015	0910015	Ball bearing
313	23132045	Bail wire assy.	0910013	0910013	Ball bearing
315	23150075	Line roller	0920589	0920589	Washer
316	23160011	Bushing	0920245	0920245	Washer
317	23170008	Line rollerwasher	0920209	0920209	Washer
318	23180008	Rotor nut	0920168	0920168	Washer
400	240016483	Spool assy.	0920169	0920169	Washer
405	24050031	Drag washer retainer	0920539	0920539	Washer
407	24070006	Extension spring	0930452	0930452	Screw
500	25006803	Handle assy.	0930575	0930575	Screw
504	25040008	Handle screw cap washer	0930562	0930562	Screw
513	25130869	Handle cap	0930945	0930945	Screw
600	26004639	Drag knob assy.	0930044	0930044	Screw
610	26100053	Drag washer	0930763	0930763	Screw
611	26110021	Eared washer	0930471	0930471	Screw
612	26120063	Key washer	09301271	09301271	Screw
612-2	26120064	Key washer	09301189	09301189	Screw
700	27000332	Drive gear	0930964	0930964	Screw
702	27020897	Pinion gear	0930819	0930819	Screw
705	27050073	Transmission gear	0930663	0930663	Screw