



CXT-20 PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21004239	Main body	612-1	26120054	Key washer
105	21056602	Pinion bearing fixed bushing	700	27000445	Drive gear
105-1	21056616	Pinion bearing fixed bushing	702	27020522	Pinion gear
108	21081443	Cap	705	27050153	Transmission gear
200	22004477	Side plate	705-1	27050222	Transmission gear
201	22010379	Main body decoration	708	27080130	Oscillating slider
201-1	22010380	Side plate decoration	716	27160026	Oscillation slider plate
201-2	22010626	Main body decoration	718	27180835	Main shaft
201-3	22010627	Side plate decoration	719	27190025	Click gear
300	23005309	Rotor	722	27220009	Click gear washer
301	23012406	Bail arm	800	28000333	Anti-reverse/anti-re lever
304	23042861	Bail arm cover	800-1	28000402	Anti-reverse/anti-re lever
305	23050232	Kick lever	801	28010024	Anti-re lever spring
307	23071974	Bail holder	0910618	0910618	One way assy.
309	23090051	Bail arm support pin	0910215	0910215	Ball bearing
310	23100090	Compression spring	0910051	0910051	Ball bearing
313	23131999	Bail wire assy.	0910039	0910039	Ball bearing
315	23150086	Line roller	0910335	0910335	Ball bearing
316	23160014	Line roller bushing	0920136	0920136	Washer
317	23170014	Line roller washer	0920590	0920590	Washer
318	23180005	Rotor nut	0920235	0920235	Washer
320	23200122	Rotor balance weight	0920600	0920600	Washer
400	240016602	Spool assy.	0930541	0930541	Screw
400-1	240016722	Spool assy.	09301547	09301547	Screw
405	24050042	Drag washer retainer	09301427	09301427	Screw
407	24070047	Extension spring	0930928	0930928	Screw
412	24120038	Spool bushing	09301376	09301376	Screw
500	25006364	Handle assy.	0930438	0930438	Screw
513	25130467	Handle cap	09301327	09301327	Screw
515	25150002	Handle screw cap washer	09301379	09301379	Screw
600	26003769	Drag knob assy.	09301450	09301450	Screw
610	26100011	Drag washer	09301492	09301492	Screw
612	26120006	Key washer	09301426	09301426	Screw