



FLS35-1500AY PARTS LIST

KEY NO	PART NO	PARTS NAME	KEY NO	PART NO	PARTS NAME
100	21005146	Main body	718	27180627	Main shaft
105-1	21056580	Pinion bearing fixed plate	719	27190041	Click gear
108	21081733	Rear cap	721	27210026	Main shaft bushing
123	21230001	Oil filler cap	722	27220056	Click gear washer
125	21250001	Pinion bearing fixed plate	725	27250038	Transmission gear bushing
200	22004942	Side plate	733	27330019	Line guide support bar
300	23005557	Rotor	734	27340012	Line guide pwal bushing
301	23012492	Bail arm	737	27370001	Worm shaft plate
304	23043643	Bail arm cover	738	27380001	Worm shaft gear
305	23050251	Kick lever	800	28000413	Anti-reverse/anti-re lever
306	23061097	Bail holder cover	801	28010048	Anti-re lever spring
307	23072105	Bail holder	816	28160001	Anti-reverse/anti-re lever
309	23090037	Bail arm slider	19000004	19000004	E retainer
310	23100108	Compression spring	0910701	0910701	One way bearing
313	23132126	Bail wire assy.	0910303	0910303	Ball bearing
315	23150110	Line roller	0910221	0910221	Ball bearing
316	23160011	Line roller bushing	0910271	0910271	Ball bearing
318	23180039	Rotor nut	0910145	0910145	Ball bearing
327	23270022	Defend winding retainer	0910018	0910018	Ball bearing
334	23340004	Rotor decoration plate	0910728	0910728	Ball bearing
400	240017374	Spool assy.	0920375	0920375	Washer
400-1	240017100	Spool assy.	0920675	0920675	Washer
400-2	240017378	Spool assy.	0920673	0920673	Washer
405	24050086	Drag washer retainer	0920168	0920168	Washer
407	24070051	Extension spring	0920249	0920249	Washer
419	24190062	Spool support plate	0920589	0920589	Washer
500	25007286	Handle assy.	0920409	0920409	Washer
513	25130995	Handle cap	0930448	0930448	Screw
600	26004814	Drag knob seat	0930544	0930544	Screw
610	26100154	Drag washer	0930364	0930364	Screw
611	26110056	Eared washer	0930058	0930058	Screw
612	26120156	Key washer	09301213	09301213	Screw
700	27000459	Drive gear	0930431	0930431	Screw
702	27020536	Pinion gear	09301268	09301268	Screw
706	27060026	Worm shaft gear	0930945	0930945	Screw
707	27070002	Transmission gear shaft	09301538	09301538	Screw
708	27080200	Oscillating slider	0930819	0930819	Screw
712	27120012	Worm shaft	09301355	09301355	Screw
715	27150006	Line guide pawl	0940091	0940091	Oring
716	27160042	Oscillation slider plate			