



Key	Parts No.	Parts name	Key	Parts No.	Parts name
1	2D1-111-01	PRESET DRAG KNOB	34	2E1-020-02	B22-055 SCREW
2	2Q1-089-01	COMPRESSION SPRING	35	2YA-054-01	ANTI-REVERSE RIATE ASSEMBLY
3	2L3-035-01	CLICK LEAF SPRING	36	2Z1-036-05	617-6 BALL BEARING
4	2A2-145-01	DRAG CAM	37	2E2-030-02	F20M-050 SCREW
5	2D4-033-01	DRAG LEVER	38	2F5-648-01	BRAKE DISC COVER
6	2W1-260-02	120-169 WASHER	39	2G2-232-01	PINION GEAR
7	2P1-075-01	CLICK PLUNGER	40	2E4-006-01	DRAG WASHER RETAINER
8	2Q1-146-01	CLICK PIN SPRING	41	2A3-055-01	ANTI-REVERSE RATCHET
9	2E2-110-01	H30-70 SCREW	42	2D3-104-01	BRAKE DISC
10	2C3-089-01	LEVER ARM SPACER	43	2D3-103-01	STOPPER PLATE
11	2F5-646-01	DRAG LEVER QUADRANT	44	2E4-015-01	DRAG WASHER RETAINER
12	2E2-006-03	B26M-050 SCREW	45	2Z1-019-05	612-4 BALL BEARING
13	2F6-043-02	HOLDING PLATE	46	2Q1-155-01	DRAG SPRING
14	2E3-075-01	NUT	47	2W3-055-01	EARED WASHER
15	2YH-613-01	HANDLE TOTAL ASSEMBLY	48	2S1-641-01	SPOOL
16	2F5-625-01	DRIVE GEAR SHAFT COVER	49	2F8-182-01	CLICK PLATE
17	2Z1-046-05	816-4 BALL BEARING	50	2E4-028-01	DRAG WASHER RETAINER
18	2E2-109-01	H30-100 SCREW	51	2W1-087-03	060-080 WASHER
19	2S3-045-01	STRIKE BUTTON	52	2L1-008-01	SPRING WASHER
20	2Q1-039-01	LINE CLIP SPRING	53	2M3-217-01	MAIN SHAFT
21	2E5-006-01	E2.5 RETAINER	54	2E1-075-01	B22-045 SCREW
22	2P1-086-01	FREE SPOOL BUTTON	55	2Q2-028-01	SPRING
23	2B2-185-01	BODY COVER	56	2F4-029-01	CLICK PAWL
24	2E1-073-01	B20-060 SCREW	57	2L5-031-01	CLICK PLATE
25	2F5-647-01	DUST COVER	58	2F7-014-01	CLICK SWITCH
26	2E2-056-01	F30M-060 SCREW	59	2E1-059-01	F20-060 SCREW
27	2F6-039-01	COUPLING PLATE	60	2F5-622-01	SPACER BAR INSERT
28	2M3-211-02	DRIVE SHAFT	61	2YB-324-01	BODY ASSEMBLY
29	2G1-213-01	DRIVE GEAR	62	2E2-081-01	X50M-310 SCREW
30	2W1-152-01	111-146 WASHER	63	2F6-066-01	ROD CLAMP
31	2Z1-034-05	1019-7 BALL BEARING	64	2E3-069-01	ROD CLAMP NUT
32	2P1-078-01	ANTI-REVERSE PAWL PIN	65	2X3-007-01	HEX WRENCH
33	2YA-045-01	ANTI-REVERSE PAWL ASSEMBLY	66	2X3-010-01	WRENCH

