SPHEROS SW 6000HG



Part No.	Description
RD 0582	O Ring
RD 8247	Ball Bearing
RD 8999	Click Pin
RD 9087	Spacer
RD 9903	O Ring
RD10752	Spring Guide A Support Collar
RD10753	Ball Spring
RD11717	Spool Support A
RD13034	Screw
RD13222	Bushing
RD13620	Screw
RD14171	Bushing
RD14979	Spool Support B
RD15200	Screw
RD15627	Drag Click
RD16251	O Ring
RD16319	Key Washer
RD16321	Drag Washer
RD16326	Screw
RD16332	Washer
RD16334	Bushing
RD16335	Ball Trip Lever
RD16337	Ball Spring Cover
RD16339	Ball Hold Support Guard
RD16342	Screw
RD16343	Clutch Water Proof Cover
RD16344	Roller Clutch Water Proof
RD16345	Rotor Ring
RD16346	Roller Clutch Assembly
RD16347	O Ring
RD16349	Friction Ring
RD16360	Screw
RD16382	Retainer

Part No.	Description
RD16569	Eared Washer
RD16571	Line Roller
RD16641	Bearing Water Proof
RD17378	Screw
RD17391	Screw
RD17398	Ball Spring Guide A
RD17412	Spool Washer
RD17414	Collar
RD17417	Screw
RD17622	Screw
RD17700	Screw
RD17863	Bushing
RD18410	Drag Click Spring
RD19026	Washer
RD19745	Washer
RD19754	Screw
RD19990	Ball Bearing
RD20293	Handle Knob Assembly
RD21053	Rotor Nut
RD21064	Spacer
RD21069	Rotor Nut Lock Plate
RD21070	Oscillating Gear
RD21075	Oscillating Guide
RD21078	Bearing Water Proof
RD21082	Body Seal
RD21083	Bushing
RD21090	Drive Gear Assembly
RD21092	Washer
RD21095	Rear Protector
RD21096	Screw
RD21097	Handle Screw Cap
RD21099	O Ring
RD21180	

Part No.	Description
RD21182	Pinion Gear
RD21224	Ball Bearing
RD21225	Screw
RD21471	O Ring
RD21653	Click Spring
RD21689	Drag Knob Assembly
RD21692	Bail Assembly
RD21693	Body Assembly
RD21694	Main Shaft Assembly
RD21696	Handle Shank Assembly
RD21698	Handle Assembly
RD21699	Handle Shaft Cover Assembly
RD21704	Rotor
RD21705	Bail Arm
RD21711	Handle Knob ID Plate
RD21714	Washer
RD21718	Screw
RD21720	Spool Assembly
RD21721	Side Cover Assembly

Please note that the number of adjusting washers may not always be the same as shown in the exploded views.
Please note that your actions take full responsibility when you take it apart.

(51SF53M063X)