TWIN POWER XD

C5000XG



Part No.	Description
RD 0582	O Ring
RD 0647	Screw
RD 2110	Screw
RD 3538	Spool Support A
RD 3561	Screw
RD 6008	Set Screw
RD 6920	Washer
RD 8074	Bearing Water Proof
RD 8165	Washer
RD 8759	Click Pin
RD 9833	Ratchet Spring
RD 9909	Eared Washer
RD 9910	Key Washer A
RD 9912	Bearing Retainer
RD 9931	Click Spring
RD 9968	O Ring
RD11646	Drag Click Ratchet
RD13241	Ball Bearing
RD13269	Ball Bearing
RD13274	Ball Bearing
RD13317	O Ring
RD13381	Ball Bearing
RD14259	Washer
RD14300	Spool Bearing Bushing
RD14780	Screw
RD15489	Drag Click Spring
RD15718	Screw
RD15727	Handle Knob Seal
RD15992	Rotor Nut
RD16465	Handle Shaft Seal
RD16587	Key Washer B
RD16616	Oscillating Pawl Cover
RD16618	Oscillating Pawl
RD16838	Main Shaft Spacer Assembly
RD17467	Bail Spring
RD17468	Bail Spring Guide B
RD17522	Bushing
RD17562	Worm Shaft Retainer
RD17681	Line Roller Support
RD17750	Bearing Housing
RD17751	Ball Bearing
RD17752	Washer

Part No.	Description
RD18160	Collar
RD18161	Line Roller Set
RD18210	Screw
RD18358	Spacer
RD18450	Screw
RD18455	Screw
RD18465	Screw
RD18711	Drag Click Screw
RD18724	Spring Guide A Support Collar
RD18726	Bail Spring Guide A Bush
RD18732	Rotor Ring
RD18733	Friction Ring
RD18735	Roller Clutch Assembly
RD18736	Roller Clutch Case Seal
RD18737	Roller Clutch Inner
RD18738	Bearing Retainer
RD18746	Bail Trip Strike
RD18747	Flange Water Proof
RD18758	Washer
RD18762	Washer
RD18977	Washer
RD18978	Oscillating Guide A
RD18979	Idle Gear
RD18988	Oscillating Slider Bushing
RD18991	Worm Shaft
RD18993	Idle Gear (Small)
RD19001	Idle Gear (Large)
RD19029	Washer
RD19090	Screw
RD19139	Screw
RD19140	Screw
RD19143	Screw
RD19195	Washer
RD19224	Washer
RD19351	Main Shaft Assembly
RD19362	Bail Hold Support Guard
RD19365	Bail Trip Lever
RD19366	Rotor Brim
RD19368	Pinion Gear
RD19369	Drive Gear
RD19375	Rear Protector
RD19411	Handle Shaft Cover B

Part No.	Description
RD19703	Ball Bearing
RD19744	Washer
RD19745	Washer
RD19746	Washer
RD19747	Washer
RD19803	Handle Screw Cap
RD19857	Bail Spring Guide
RD19926	Nut Lock Plate
RD19976	Bushing
RD20124	Washer
RD20282	Idle Gear Shaft
RD20436	Washer
RD20636	Screw
RD20735	Drag Washer A
RD20737	Drag Washer B
RD20903	Ball Bearing
RD21441	Drag Knob Assembly
RD21455	Bail Arm
RD21456	Bail Assembly
RD21457	Rotor Assembly
RD21458	Body
RD21460	Rear Shield
RD21461	Handle Assembly
RD21462	Handle Shank Assembly
RD21463	Handle Knob Assembly
RD21466	Spool Assembly
RD21467	Side Cover Assembly
RD21764	Retainer

S A-RB
(51SF47H049X)

Please note that the number of adjusting washers may not always be the same as shown in the exploded views.
Please note that your actions take full responsibility when you take it apart.

(220425)_002